



Classic 2000-HOB


Instruction Manual



HONYA CO., LTD
www.reefoctopus.com



Explosion Chart for *Classic 2000-HOB*



2+10) 4020113004
25+26) 4020113001
19+23+24+25+26) 4020113002
3+4+16+18) 4020113003

Hang-on Back External skimmer

Installation

- Remove the skimmer body and all the assembly parts. Please refer to the checklist.
- Install the product as shown.
- Hang it on the back of the tank, position before tightening the screw. Make sure it is secured.
- Fill the skimmer body until the water level up reaches approximately 8 inch / 20cm, shut off the air valve completely, turn ON the power. Turn on the air valve as soon as the pump start running. When the micro bubbles start foaming, insert the air hose into the silencer.
- An ideal water level will have foaming on the brim of the collection cup.

Maintenance

- Collection Cup: Collection Cup should be cleaned at least once every 7-10 days, depending on the organic waste collected.
- Skimmer body: It is recommended that you clean the Skimmer Body once every 3-6 months. Clean and rinse off with fresh water only.
- Silencer: It is recommended to clean the silencer once every 2-3 months to prevent blockage.
- Pump: It is recommended to clean the Pump once every 3-6 months. Check and Clean the Impeller and pump chamber. If necessary, soak the Pump and Impeller in White Vinegar to dissolve stubborn calcium deposits.

Safety Tips

- The voltage shown on the label of the Pump must corresponds to the voltage of your power supply
- Always unplug the pump before maintenance
- Never run the pump dry
- Do not clean the Skimmer with any cleaning agents

Warranty

Please refer to the below URL:
<https://reefoctopus.com/services/warranty/>

HONYA CO., LTD is committed to continuous product development, we hereby reserve the right to revise the product specifications or designs without prior notice. For any further enquiry/assistance and latest product updates, Please Visit at www.reefoctopus.com.